

AA65 Retrofit Kit - Padlock

Kit will include:

- 2 padlocks
- 1 instruction sheet
- 1 rubber square with tape on one side
- 1 'L' angle bracket
- 2 angle bracket screws
- 1 white weather guard

1. Remove any key lock from box.
2. Screw the 'L' angle bracket to the bottom of the bracket on the inside of the box with the screws.
3. Place rubber square on the inside of the box using the strips of tape to adhere.
****For more durability and weather resistance, use contact cement or silicone on taped side of rubber before placing the rubber down. Wait until the glue has dried or is completely stuck before going to step 4.**
4. Close the box and push gently on the rubber until you can see a slight indent of the bracket through the rubber. With a sharp utility knife make a slice in the rubber just large enough for the bracket to fit through.
5. Place white weather guard over rubber.
6. Place one padlock on the box and leave the other padlock inside the box.